

To determine if extension cables are needed, measure the distance from the proposed mounting location of the AC110 console to each of the vehicle's components like we show on the previous page, taking into account that the Single Product Dry cable harness is 15 feet in length itself.

