

CAN0/CAN1 Logging

Navigate to
diagnostics>terminal>CAN0.

Automatic activation starts a
log on every bootup.


Press start to start a new
CAN0 log.



Started log shall be identified
by date timestamp.

When event is captured, user
shall press stop.


If a user forgets to stop CAN0
log it shall be added to files at
startup.



Stopping log shall add the
recorded log to the export
file.


Pressing export adds the
CAN0 log to files.

Should a user forget to
export the log it shall be
added to files on reboot.



Navigate to
diagnostics>terminal>CAN1.

AC110



Follow same procedure
used in collecting CAN0
data.

