


Connect Implement

- Connect IBBC on Rear of Machine – Connect MAX in Cab



Open ISO VT

- Icon in bottom left will open ISO Window



Implement Should Load Automatically

- Implement will display in ISOVT Window (Object Pool loads)



Setup Implement

- Configure implement in ISOVT window then setup implement in MAX (similar to an AC110) For ISO TCs

