

Blink Code	Reason for Fault	Corrective Action
21	WAS above normal operation	Adjust sensor values below 4750
22	WAS below normal operation	Adjust sensor values above 250
23	Sensor power out of range	Repair/Replace sensor power wiring
24	Steer L Open/Short	Either plug in Left coil cable or cable is bad
25	Steer R Open/Short	Either plug in Right coil cable or cable is bad
26	Enable Valve Open/Short	Either plug in valve cable or cable is bad
27/28	CAN communication fault	-
29	Reset Required	Reboot Plus1 steering controller/Replace Plus1
32	Possible damaged or loose cable	Check cable btwn EDX and Plus1 for connection and/or damage
34	Possible pressure transducer failure	Swap out pressure transducer